



Tech Bulletin



Tech Bulletin Number: MVTB-100202

Date: October 15, 2002

Product Part Number: PROVD8/VOD806

Product Description: 8" overhead DVD player

Situation/Problem: Some movies will not play in the PROVD8/VOD806

Solution: Upgrade the software in the unit to allow it to play newer releases.

Note: This upgrade is designed to allow the PROVD8/VOD806 to play the majority of movies. Some new releases are known to be problematic in some home and auto players as well as computer DVD drives.

Instructions: See below for upgrade procedure (if you do not have a disc, the software can be downloaded and burned to a CDR at the Audiovox web site (www.audiovox.com)). See page 3 for instructions.

PROVD8/VOD806 UPGRADE PROCEDURE

Materials needed:

- 1- **CDR with software upgrade labeled: (see last page for creating your own disc)**

**Audiovox
PROVD8/VOD806
Software Upgrade Disc
Ver. y013z25_021015_B3 Rel 01 -A
P/N 122-1017 Date: 10/15/02**

- 2- **PROVD8/VOD806 Remote Control**

1. Turn on the DVD player and switch to DVD mode

2. Insert the CDR disc in the DVD player. The screen will display "LOADING" (This takes about 15 seconds)



For additional information or installation help, call 1-800-225-6074
Monday through Friday: 8:30 AM to 7:00 PM EST, Saturdays: 9:00 AM to 5:00 PM EST



Tech Bulletin



3. Next the screen will display
"PRESS ENTER TO UPGRADE EJECT TO CANCEL"

Using the remote control, press the "ENTER"
key.

NOTE: This message will disappear after a
period of time. You can still press the **ENTER**
key to upgrade.



4. Screen will read
"UPGRADING...REMOVE DISC AFTER IT IS DONE".

(This takes approximately 35 seconds)

Screen will go blank after the upgrade is
complete and the splash screen will reappear.

Remove the disc.

IMPORTANT: Shut off the unit and turn it
back on to complete the upgrade.



NOTE: To check the software version of the unit with the remote control, use the following procedure:

Press **STOP**, **▲**, **▼**, **◀**, **▶** and **Enter**. The software version will be displayed in the lower
left hand side of the screen. It will only appear briefly. To see it again, repeat the
above procedure. The software version should read **y013z25_021015_B3 Rel 01 -A**

For additional information or installation help, call 1-800-225-6074
Monday through Friday: 8:30 AM to 7:00 PM EST, Saturdays: 9:00 AM to 5:00 PM EST



Tech Bulletin



CREATE YOUR OWN CD-ROM

- 1) Download the file off the website and save to your desktop
- 2) Double click on the ZIP file to unzip the file. (NOTE: You must have WinZip installed on your computer. To download a free evaluation copy please go to WWW.WINZIP.COM.)
- 3) Unzip/Extract the contents of the ZIP file to your desktop. (Note: There should be a folder called "upd500c" and 3 files inside called "Ati_y013z25_1015_B3.txt", "ome528c.bin", and "ome528c.dat".)
- 4) Place a Blank CDR disc into your CD burner drive and open your burn software.
- 5) Add the folder to the root (top level) of the CDR. (Note: The Root should only show the folder "upd500c" not the files. The files are located inside the folder.)
- 6) Record that data to the disc. It should take about 2 minutes to finish the record process.
- 7) Label the CDR
- 8) Follow instructions on page 1 for details on how to upgrade the unit.

For additional information or installation help, call 1-800-225-6074
Monday through Friday: 8:30 AM to 7:00 PM EST, Saturdays: 9:00 AM to 5:00 PM EST